

S/NO	ITEM	SILKSCREEN	OFFSET
1	Half-Tone	25-35 lines/cm (65-85 lines/inch)	60-80 lines/cm (Max. 150 lines/inch)
2	Colour Film	Positive, Emulsion Up	Negative, Emulsion Down
3	Base Film	Required-Positive Emulsion up	Positive, Emulsion Up
4	Lettering	Minimum 0.3mm spacing	
5	Colour Code	Indicate on Film (See above)	
6	Colour-Proof	Required	
7	Art Work Dot Grain Size	Equivalent to that of Film	
8	Cross Mark	Same location for all Film	
9	Center Hole (A)	3 Choices * 18.00mm * 26.00mm * \geq 36.00mm	
10	Groove Area	No printing on Groove Area (B) = 1.0mm	


Film Template

The enclosed film templates (DigicaD 18/30 MB, Snap 'N' Play, Heart Shape) are for checking of image supplied for surface printing of the DigicarD.

The image should not exceed the outline as indicated.

To check, lay the template over the films or laser proofs supplied by your client.

Please note that the outer ring is the sensor ring for positioning of the CD-ROM during stamping. See diagram below.



Film Template

The enclosed film templates (DigicaD 18/30 MB, Snap 'N' Play, Heart Shape) are for checking of image supplied for surface printing of the DigicarD.

The image should not exceed the outline as indicated.

To check, lay the template over the films or laser proofs supplied by your client.

Please note that the outer ring is the sensor ring for positioning of the CD-ROM during stamping. See diagram below.

